

ARTISAN TOP TOUCH UP

Instructions to touch up an Artisan acid washed Supercast top if there is a chip in the top.

Items included in touch up kit

- Empty mixing container
- Barnwood black color
- Barnwood walnut color

Items needed

- Damp cloth
- Dry cloth
- Sealer (recommend SC-SEALER, can be ordered from OGC)

Wipe off damaged area with a damp cloth

Take small amount of the Barnwood walnut and using the dropper apply a few drops to the chipped area. This will give a lighter finish.

Take a small amount of the Barnwood black and using the dropper apply a few drops, mixing in with the walnut color. The more black that is added the darker the color will appear.

Take a dry cloth and dab the mixtures together until it is blended evenly and the affected area has taken color.

You may need to add more of one color to achieve a close match to the affected area.

Let dry and then apply a sealer to the area. We recommend SC-SEALER