
Assembly Instructions

BEFORE YOU BEGIN:

- 1. Identify all parts in the box against the "Parts" List.
- 2. Remove all protective material carefully and avoid cutting the surface of the furniture while removing wrapped material.



Part		Description	Qty
A		Table Top	1
В		Center Plate	4
С		Table Leg	4
D		Headless Bolt	4
E		Flat Washer	12
F	\bigcirc	Lock Washer	12
G		Nut	12

Assembly Instructions

(FOR 201088-WCH)

ATTENTION:

1. DO NOT use power tools or over-tighten hardware during assembly.*

*Aluminum is soft metal, so over-tightening may strip threads or break the parts.

2. Please read these instructions carefully before assembling.

3. During assembly, place furniture against soft surfaces to avoid scratching the paint/ metal.

ASSEMBLY STEPS:

- 1. Place the TABLETOP (A) upside down onto a clean and soft, non-abrasive surface.
- 2. Screw the short side of the HEADLESS BOLTS (D) into the 4 holes of the TABLETOP.
- 3. Loosely secure the LEGS (C) to the TABLETOP using FLAT WASHERS (E), LOCK WASHERS (F), and NUTS (G). *Do not tighten at this time.
- 4. Position the **CENTER PLATES (B)** between the **LEGS** so that the holes on the center plate are inserted onto the bolts on each leg.

CAUTION

When securing the center plates to the legs, the <u>FLAT</u> side of the center plate always goes on to the leg first. The <u>CURVED</u> side of the adjacent center plate goes onto the leg AFTER the FLAT side is on.

- 5. Secure the parts together using FLAT WASHERS (E), LOCK WASHERS (F), and NUTS (G).
- 6. Tighten all bolts and nuts completely.
- 7. Turn the table onto its legs.
- 8. If needed, you may use the adjustable feet to level out the table.

CARE INSTRUCTIONS:

Please DO NOT use acid or alkaline washing liquids to clean this product. Harsh cleaners can cause the powder-coated finish to stain and fade. Use a soft towel with mild liquid soap and water to clean the product, and dry with a soft cloth.