


# KETTLER


## **Mesh Top Tables**



#### For the following products:

T0445-0200S	T0422-0200S
T0450-0200S	T0425-0200S
T0410-0200S	T0470-0200S
T0485-0200S	T0416-0200S


#### **Parts List**



#### Helpful advise before you begin:

- 1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
- 2. If you follow the instructions carefully the end result should be worth the effort.
- 3. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
- 4. Assemble this product on a soft surface.
- 5. To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
- 6. Keep fittings out of children's reach.
- 7. Do not use any other tools other than those recommended to build this product.
- 8. Please do not use substitute parts. Use only additional or replacement parts supplied by Kettler.
- 9. In the unlikely event that this product has missing or damaged parts, please call 866-804-0440 to obtain spares.

## **Assembly Instructions**



#### For your safety

- This product may only be used for its intended purpose as outdoor furniture for residential spaces.
- Check all components regularly for correct functioning, damages and loosened connections especially at the beginning of the season.
- Damaged components may endanger your safety or shorten the life of the product. Replace all damaged parts immediately. Use only spare parts manufactured by Kettler.
- Incorrect repairs or alterations to the product (e.g. removal of original Kettler parts and their replacement with non-Kettler parts) may endanger the user's safety. Should you wish to purchase spare parts, please contact Kettler at 866-804-0440
- The manufacturer is not liable for damage to the product caused by improper use.

### ① Attention

- While assembling this product keep out of the reach of children. (Choking hazard contains small parts)
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around.
- Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- · We reserve the right to make changes for technical reasons.

Please keep these assembly instructions for any spare parts orders



KETTLER® International Inc. 1355 London Bridge Road Virginia Beach,VA 23453 USA www.kettlerusa.com

For Parts and Service, please contact us directly at 866-804-0440 or email parts@kettlerusa.com

2022 KETTLER®. All rights reserved. Made in China

We reserve the right to make changes or discontinue any items with or without prior notice.