


# Tommy Bahama®

## OUTDOOR LIVING

### ASSEMBLY INSTRUCTIONS

#### 3235-877 Rectangular Dining Table



1. Place table upside-down on clean, flat, non-marring surface.
2. Insert leg into corner of top so that holes in leg align with holes in corner of top.
3. Use wrench to attach leg to top with (2) flat washers, (2) lock washers, and (2) bolts. Fully tighten bolts.
4. Repeat steps 2 & 3 for other (3) legs.
5. Return assembled table to its upright position and place in desired location.

For additional consumer assistance please contact your Tommy Bahama Outdoor Living dealer or call our Consumer Services Department at 1-336-474-5444, Monday-Friday, 8-5 Eastern