

REQUIRED CLEARANCES FOR SAFE TABLE SETUP

Applicable for:
BSTRD. Core Large
BSTRD. Pro Large

Disclaimers:

Users of this information can not derive any rights from or make claims based on the accuracy or completeness of its content. Every BSTRD. is unique. Therefore, check this information before installing your BSTRD. Make sure to allow for sufficient clearance, also accounting for the behaviour of the ceramic.

Your BSTRD. will get very hot during use. Keep a minimum clearance of 3 meters (10ft.) from any combustible materials. Ensure that all parts of the table and the back wall are made of heat resistant materials or are properly insulated. The user is fully responsible for any damage, discoloration, or burn marks caused by heat.

BSTRD.

