



1) Verify the Contents



Master
Speaker



Pairing
Speaker



100-240V
Power Supply
for Master Speaker




13 Foot Speaker Wire
To connect the speakers
together for stereo R&L

2) Pick Your Speakers Power Source Electrical or AA Battery Setup:


Electrical Power Supply Setup ~

- Remove the battery box before connecting to power source.
- Place Master Speaker near 12 volt AC outlet so the Power Supply can be connected. This will provide electrical current needed for the Internal Amplifier & Bluetooth Receiver.
- Make sure that the Power Supply Block will **NOT** be sitting in water.
- The Pairing Rock Speaker must be connected to the Master Rock Speaker using the 13-foot speaker wire supplied. The speaker wire can be cut down for an exact fit but should **NOT** be extended beyond 13-feet. Turn power button on. Red LED indicator light will light up when power is on.



AA Battery Power Supply Setup ~

- Unscrew battery cover, insert 6 AA batteries. Note position of positive and negative poles.
- Place battery pack in battery compartment. Connect the two metal springs on the bottom of the battery compartment with the two metal chips on the bottom of the battery pack.
- Replace the battery cover and tighten.
- Turn power button on. The green light will turn on.



Note: When using batteries, it is suggested that the volume on the Bluetooth device be set at no more than 60%. This will help prolong the battery life.


BTR-150

All Weather Bluetooth Rock Speakers Quick Start Guide


3) Pair Bluetooth Device With BTR-150

- Make sure both your Bluetooth device and the BTR-150 are turned on and charged up.
- Find Bluetooth controls. Typically found in the devices' Settings or Connections menu.
- The BTR-150 will output a Bluetooth Sync code that will be received by your Bluetooth device. Sync device.
- Once synced, the controls (such as volume, mute, etc.) will be done directly from your Bluetooth device.

Note: The BTR-150 can only sync with one device at a time. You must disconnect the current device before syncing to another device.




Bottom View



- 1) Battery Cover
- 2) DC to AC In
- 3) On/Off Power Button
- 4) Green LED Indicator
- 5) Red LED Indicator

Bluetooth Range May Vary:
Line of Sight
120 to 150 feet (Unobstructed)
50 to 75 feet (Obstructed)



"Wireless" Bluetooth Operation connects to any Bluetooth-enabled device such as smart phones, tablets and laptop/computers.

**Ideal for Lawn
and Garden Placement**

OSD Audio
775 Columbia St. • Brea, CA 92821
(888) 779-4968 • www.osdaudio.com