












Assembly Instructions

BEFORE YOU BEGIN:

1. Identify all parts in the box against the “Parts” List.
2. Remove all protective material carefully and avoid cutting the surface of the furniture while removing wrapped material.



Part		Description	Qty	Part		Description	Qty
A		Table Top	1	D		Headless Bolt	4
				E		Flat Washer	12
B		Center Plate	4	F		Lock Washer	12
C		Table Leg	4	G		Nut	12
				H		Nut Cap	12

Assembly Instructions

(FOR DL30-I)

ATTENTION:

1. **DO NOT** use power tools or over-tighten hardware during assembly.*

*Aluminum is soft metal, so over-tightening may strip threads or break the parts.

2. Please read these instructions carefully before assembling.

3. During assembly, place furniture against soft surfaces to avoid scratching the paint/ metal.

ASSEMBLY STEPS:

1. Place the **TABLETOP (A)** upside down onto a clean and soft, non-abrasive surface.
2. Screw the short side of the **HEADLESS BOLTS (D)** into the 4 holes of the **TABLETOP**.
3. Loosely secure the **LEGS (C)** to the **TABLETOP** using **FLAT WASHERS (E)**, **LOCK WASHERS (F)**, **NUTS (G)**, and **NUT CAPS (H)**. *Do not tighten at this time.
4. Position the **CENTER PLATES (B)** between the **LEGS** so that the holes on the center plates are inserted onto the bolts on each leg.
5. Secure the parts together using **FLAT WASHERS (E)**, **LOCK WASHERS (F)**, **NUTS (G)**, and **NUT CAPS (H)**.
6. Tighten all bolts and nuts completely.
7. Turn the table onto its legs.
8. If needed, you may use the adjustable feet to level out the table.

CARE INSTRUCTIONS:

Please **DO NOT** use acid or alkaline washing liquids to clean this product. Harsh cleaners can cause the powder-coated finish to stain and fade. Use a soft towel with mild liquid soap and water to clean the product, and dry with a soft cloth.