
Assembly Instructions

BEFORE YOU BEGIN:

- 1. Identify all parts in the box against the "Parts" List.
- 2. Remove all protective material carefully and avoid cutting the surface of the furniture while removing wrapped material.



Part	Description	Qty
A	Table Top	1
В	Long Center Plate	2
C	Short Center Plate	2
D	Headless Bolt	4
E	Table Leg	4
F	Flat Washer	12
G	Lock Washer	12
Н	Nut	12

Assembly Instructions

(FOR DL30-RE)

ATTENTION:

- 1. **DO NOT** use power tools or over-tighten hardware during assembly.*
- *Aluminum is soft metal, so over-tightening may strip threads or break the parts.
- 2. Please read these instructions carefully before assembling.
- 3. During assembly, place furniture against soft surfaces to avoid scratching the paint/ metal.

ASSEMBLY STEPS:

- 1. Place the **TABLETOP** (A) upside down onto a clean and soft, non-abrasive surface.
- 2. Screw the short side of the **HEADLESS BOLTS (D)** into the 4 holes of the **TABLETOP.**
- 3. Loosely secure the LEGS (E) to the TABLETOP using FLAT WASHERS (F), LOCK WASHERS (G), and NUTS (H). *Do not tighten at this time.
- 4. Position the **LONG AND SHORT CENTER PLATES** (**B & C**) between the **LEGS** so that the holes on the center plates are inserted onto the bolts on each leg.
- 5. Secure the parts together using FLAT WASHERS (F), LOCK WASHERS (G), and NUTS (H).
- 6. Tighten all bolts and nuts completely.
- 7. Turn the table onto its legs.
- 8. If needed, you may use the adjustable feet to level out the table.

CARE INSTRUCTIONS:

Please DO NOT use acid or alkaline washing liquids to clean this product. Harsh cleaners can cause the powder-coated finish to stain and fade. Use a soft towel with mild liquid soap and water to clean the product, and dry with a soft cloth.