




Elysian Aluminum Patio Bar Stool



Customer Service

CustomerService@ShoppersChoice.com

Monday - Friday 7-9, Sat. 9-3, Sun. 12-6 CST

Toll Free: 1-877-743-2269









www.ShoppersChoice.com

WARNING


Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly. **DO NOT ATTEMPT TO ASSEMBLE IF PARTS ARE MISSING OR DAMAGED. IMPROPER ASSEMBLY MAY RESULT IN DAMAGE OR SERIOUS INJURY**

Place chair on a non-abrasive flat surface to prevent scratching.

PARTS LIST

Part	Picture	Description	Qty	Part	Picture	Description	Qty
A		Chair Bucket	1	E		Lock Washer	4
B		Chair Base	1	F		Nut	4
C		Bolt	4	G		Nut Cover	4
D		Flat Washer	8	H		Wrench	1

Warning: Do not force components and over tighten the nuts and bolts during assembly.



ASSEMBLY

1. Remove all protective material carefully. Avoid cutting the surface of the furniture while removing the packaging material.
2. Place the chair bucket (A) on a non-abrasive flat surface. Align the holes on the support bar on the underside of the chair bucket with the holes on the spring plates attached to the t-rocker that is pre-attached to the base (B). Insert bolts (C) through the support bar and the metal plate as shown in the diagram. Loosely secure Bolts (C) with flat washers (D), lock washers (E), nuts (F).
Warning: Improper assembly may result in serious personal injury.
3. Once all the nuts (F) and bolts (C) are in place, securely tighten all the bolts (C) and nuts (F) with the hex wrenches (H). Cover all nuts (F) with nut covers (G). Test the barstool gently. If the barstool does not rock properly, double check the assembly procedure, especially step 2.