



Instant, ultra-precise meat
& ambient temperature probe

EN Connect jack to GrillEye® Max
DE Thermometer mit dem GrillEye® Max verbinden
FR Connectez le jack au GrillEye® Max
IT Collegare il GrillEye® Max
ES Conecte el GrillEye® Max

EN Remove before use
DE Bitte vor Gebrauch entfernen
FR Enlever avant usage
IT Si prega di rimuovere prima dell'uso
ES Quitar antes de usar

EN Attach to grill
DE An Grill anschließen
FR Attachez au grill
IT Attaccare alla griglia
ES Enganche el dispositivo
junto a la parrilla

Smoke

Grill

EN Insert in meat
DE In Fleisch einführen
FR Insérez dans la viande
IT Inserire nella carne
ES Introducir la sonda en
las piezas de carne








EN Caution - Hot
DE Vorsicht - heiß
FR Attention - Chaud
IT Attenzione - Caldo
ES Cuidado - Mui Caliente



SAFETY
ACCURACY
CERTIFIED



works only with GrillEye® Max | extendable length with GrillEye® Wire Extender | made for any grill, smoker, oven or cooktop

	EN	DE	FR	IT	ES
	When in use, grip may be hot. Use caution.	Bei Verwendung kann sich der Griff erhitzen. Vorsicht walten lassen.	Le manche est chaude pendant l'utilisation. Soyez prudents.	Quando è in uso, il manico potrebbe risultare molto caldo. Fare attenzione.	Cuando esté en uso, las agarraderas pueden estar calientes. Tenga cuidado.
	Not to be used with induction cookers.	Nicht mit Induktionsherden verwenden.	Ne pas utiliser sur les plaques à induction.	Da non usare con le piastre a induzione.	No debe utilizarse en cocinas de inducción.
	Do not expose directly onto fire.	Nicht direkt dem Feuer aussetzen.	N'exposez pas directement aux flammes.	Non mettere a contatto diretto col fuoco.	No exponerlo directamente al fuego.
	Avoid submersion into water. Do not put inside the dishwasher.	Nicht in Wasser eintauchen. Nicht spülmaschinengeeignet. Mit feuchtem Tuch und wenig Seife reinigen.	Ne plongez pas dans l'eau. Ne lavez pas à la lave-vaisselle.	Non immergere in acqua. Non lavare in lavastoviglie.	Cuando esté en uso, las agarraderas pueden estar calientes. Tenga cuidado.
	Keep away from children.	Von Kindern fernhalten.	Gardez loin d'enfant.	Tenere fuori dalla portata dei bambini.	Manténgase fuera del alcance de los niños.

grilleye.com

