

FRENCH COUNTRY ROUND BISTRO TABLE DMR-875

Understand and follow the care instructions. Save this document for future reference.



General Care

Regular and proper care will help preserve the quality of your furniture for many Sunnydaze to come!

- 1. Clean Often:** Use a damp cloth to clean as needed and wipe dry with a soft cloth. Never use harsh chemicals or abrasive materials to clean this item.
- 2. Protect:** Always wipe up moisture promptly and dry with a soft cloth. Avoid dragging sharp or rough objects across the surface of your wood furniture. Using coasters is recommended. Avoid direct contact with products that may react with and/or stain the wood, including, but not limited to, rubber bumper pads, glass containers, candle wax, and outdoor heating sources.
- 3. Exposure:** Over time, sunlight and weather elements may change the color of natural wood. Avoid leaving wooden furniture in the rain or high-humidity climates as wood can expand and contract with humidity changes; you may need to tighten fittings periodically. If this item is not used for extended periods, cover or store it indoors.
- 4. Winter Care & Storage:** Cover and store the furniture during the winter to protect it from ice and snow. Doing so will preserve the appearance and integrity of the item.

Any modification or failure to follow the recommended care will void the product warranty.