



mesa

tabletop fire pit suited for any outdoor space

⚠️ Must read before use. Failure to do so can result in serious injury or death.

SCAN HERE



Vor Gebrauch unbedingt lesen. Andernfalls sind schwere Verletzungen oder Todesfälle möglich. **HIER SCANNEN.**

À lire absolument avant toute utilisation. Le non-respect de cette consigne peut entraîner des blessures graves, voire mortelles. **SCANNER ICI.**

Leer antes de usar. El no hacerlo puede resultar en lesiones graves o muerte. **ESCANEE AQUI.**

Lezen voor gebruik. Het nalaten hiervan kan leiden tot serieuze verwondingen of de dood. **SCAN HIER.**

Da leggere prima dell'uso. In caso contrario, possono verificarsi lesioni gravi o morte. **SCANSIONA QUI.**



WARNING! FOR OUTDOOR USE ONLY!


USER WARNINGS Do Not use until you have read the operating instructions and user warnings. Serious injury, and /or property damage may occur

- The Mesa fire pit ("Mesa:") is for outdoor use only. Do NOT use inside any enclosed area or under overhanging structures or trees.
- Do not use Mesa for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
- **CHILD SAFETY HAZARD.** This product is not intended for use by children. Adult use only. Mesa is not a toy. Exercise the same caution you would with an open fire.
- Mesa will be extremely hot when in use. Never attempt to touch or move Mesa during use or before it has completely cooled down. Any direct contact may lead to serious injury whether accidental or otherwise. Do not lean any objects against Mesa.
- Mesa must always be used with its included stand, especially when placed directly on wood, grass, PVC, or composite materials.
- Exercise extreme caution when using Mesa on or around combustible surfaces. Use on wood, plastic, composite, or other combustible surfaces is at your own risk and can lead to charring or ignition if not adequately elevated, insulated, or misused. Even when using the stand, wood and other combustible materials differ significantly in quality and have varying heat resistance ratings. Further elevate or insulate Mesa if needed to avoid potential damage.
- Do not use gasoline, lighter fluid, or other flammable liquid to light or relight Mesa. Doing so can lead to serious injury or property damage, in particular if the flammable liquid pools in the bottom of the fire pit.
- Never leave Mesa unattended while in use, hot or while cooling off, especially if used near combustible surfaces.
- Do not lean on combustible surfaces overnight after use even if you believe it has cooled off.
- Be aware of potential damage to people and property from embers.
- Mesa is designed for use with natural fuel sources (wood, pellets) and may not function properly with other fuel sources.
- Do not alter or modify Mesa in any manner.
- Do not store or use gasoline or any other flammable vapors or liquids in the vicinity of Mesa.
- Do not wear flammable or loose clothing when operating Mesa.
- Do not use Mesa in windy conditions.
- Keep all electrical cables away from Mesa.
- Do not lean over Mesa when lighting or when they are in use.
- After a period of non-use, check your Mesa for signs of damage and creosote build-up. Do not operate until the necessary repairs and/or clean-up is done.
- Do not use water to extinguish the fire as this could cause damage to the Mesa as well as injury to the user.
- Dispose of ashes properly, in an ash-safe metal bin. Ashes can maintain heat and combustion can occur even after several hours.
- Serious injury, death and/or property damage may occur if the above instructions are not followed exactly. User assumes all responsibility for safety.


WHAT'S INCLUDED



Flame Ring






Fire Pit




Stand

GETTING STARTED

1. Read all instructions and warnings prior to use.
2. Unfold the stand legs until they lock into place.
3. Place the stand on a level surface with the black feet facing down. Make sure you are always using the stand whenever you light Mesa to reduce risk of damage to your surfaces.
4. Place Mesa in the center of the stand.






- Place Mesa's flame ring on top, facing up. This will direct your flame upwards for the best secondary burn.
- Light it up! Use Mesa with your choice of pellets, sticks, chunk wood, or kindling.



LIGHTING WOOD:




- Place your fire starter in the middle of Mesa's burn chamber.
- Use a long lighter to light the fire starter. (fig. 1)
- Start adding sticks, chunk wood, or kindling slowly. As your pieces of wood catch fire, add more as needed. (fig. 2)
- Never stack wood higher than Mesa's interior vent holes. Doing so will cut off airflow, and will cause your fire to smoke. Make sure wood is resting under the holes, and that they are clearly visible after fueling. (fig. 3)
- Fuel your fire as often as you need to keep Mesa's flame burning bright all night!



LIGHTING PELLETS:

- Add pellets to the burn chamber until they are resting right below Mesa's interior vent holes. Never add pellets higher than Mesa's interior vent holes. Doing so will cut off airflow and cause your fire to smoke. (fig. 4)
- Place a fire starter on top and in the center of the pellets. (fig. 5)
- Use a long lighter to light the fire starter. (fig. 6)
- Allow the fire starter to ignite the pellets. Add small amounts of pellets as needed.

NOTE: Adding too many pellets all at once can choke your fire, which can cause it to smoke. Be sure to add small amounts (approx. 1/4 cup) at a time.



ACCESSORIES

Elevate your night around the fire with Mesa's essential accessories:



Starters

Made of non-toxic materials so you can enjoy a safer burn



Wood Pellets

Made from 100% all-natural hardwood.



Mini Oak Firewood

Kiln-dried and cut to size fuel



Accessory Pack

Tools to fit your tabletop fire pit



Fire up s'mores night, ANY NIGHT

Get inspired by some of our favorite gourmet s'more ingredients:



Mexican Hot Chocolate S'more with Chili-Roasted Pistachios

- graham cracker
- cayenne pepper
- shelled, chili-roasted pistachios
- dark chocolate
- roasted marshmallow



Peppermint and Dark Chocolate Crunch S'more

- graham cracker
- dark chocolate
- crushed peppermints
- roasted marshmallow



Strawberry Shortcake S'more

- sponge cake
- white chocolate
- sliced strawberry
- roasted marshmallow

Share your creations with us by entering our monthly photo contest at solostove.com/photo