




Villa Flora 42 X 72 Inch Oval Table



Customer Service

CustomerService@ShoppersChoice.com

Monday - Friday 7-9, Sat. 9-3, Sun. 12-6 CST

Toll Free: 1-877-743-2269











www.ShoppersChoice.com

WARNING

Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly. **DO NOT ATTEMPT TO ASSEMBLE IF PARTS ARE MISSING OR DAMAGED. IMPROPER ASSEMBLY MAY RESULT IN DAMAGE OR SERIOUS INJURY**

Place table on a non-abrasive flat surface, and prevent from scratching.

PARTS LIST

Part	Picture	Description	Qty	Part	Picture	Description	Qty
A		Table Top	1	F		Flat Washer	12
B		Table Legs	4	G		Lock Washer	12
C		Short Leg Connector Panel	2	H		Nut	12
D		Long Leg Connector Panel	2	I		Nut Cover	12
E		Bolt(5/16*40)	4	J		Wrench	1

Warning: Do not force components and over tighten the nuts and bolts during assembly.

ASSEMBLY

1. Remove all protective material carefully. Avoid cutting the surface of the furniture while removing the packaging material.
2. From the inside of the leg connector panel (C&D), loosely attach the leg connector panel (C&D) to the table legs (B) with the pre-attached bolts on the table legs through the aligned connector panels (C&D) and secure with flat washers (F), lock washers (G) and nuts (H) . DO NOT TIGHTEN NUTS AT THIS POINTS.
3. Align the holes in table legs (B) with the holes in the table top (A). Loosely secure table legs (B) to table top (A) by inserting bolts (E) through table legs (B) and table top (A) and securing with flat washers (F), lock washers (G) and nuts (H) . DO NOT TIGHTEN NUTS AT THIS POINTS.
4. Check the alignment of all table legs (B), and adjust if necessary. Once the alignment is correct and all bolts & nuts are In place, tighten all nuts (H) using wrench (J) . Cover all nuts (H) with nut covers (I) . With the help of another person, carefully turn the table to the up-right position. The table is ready for your enjoyment.

