



Villa Flora 60 X 108 Rectangular Dining Table



Customer Service

CustomerService@ShoppersChoice.com

Monday - Friday 7-9, Sat. 9-3, Sun. 12-6 CST

Toll Free: 1-877-743-2269













www.ShoppersChoice.com

WARNING

Please read instructions carefully and thoroughly before assembling. Check parts against the parts list to make sure you have all the parts needed for proper assembly. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly. **DO NOT ATTEMPT TO ASSEMBLE IF PARTS ARE MISSING OR DAMAGED. IMPROPER ASSEMBLY MAY RESULT IN DAMAGE OR SERIOUS INJURY**

Place table on a non-abrasive flat surface, and prevent from scratching.

PARTS LIST

| Part | Picture | Description | Qty | Part | Picture | Description | Qty |
|------|---|---------------------------|-----|------|---|-------------|-----|
| A |  | Table Top | 1 | G |  | Flat Washer | 18 |
| B |  | Table Legs | 4 | H |  | Lock Washer | 18 |
| C |  | Middle leg | 2 | I |  | Nut | 18 |
| D |  | Long Leg Connector Panel | 2 | J |  | Nut Cover | 18 |
| E |  | Short Leg Connector Panel | 2 | K |  | Support | 1 |
| F |  | Bolt(5/16*40) | 6 | L |  | Wrench | 1 |

Warning: Do not force components and over tighten the nuts and bolts during assembly.

ASSEMBLY

1. Remove all protective material carefully. Avoid cutting the surface of the furniture while removing the packaging material.
2. From the inside of the leg connector panel (D&E), loosely attach the leg connector panel (D&E) and support (K) to the legs (B&C) with the pre-attached bolts on the table legs through the flat washers (G), lock washers (H) and nuts (I). **DO NOT TIGHTEN NUTS AND BOLTS AT THIS POINT.**
3. Align the holes in the legs (B&C) with the holes in the table top (A). Loosely secure table legs (B&C) to table top (A) by inserting bolts (F) through flat washers (G), lock washers (H) and nuts (I).

DO NOT TIGHTEN NUTS AND BOLTS AT THIS POINT.

Check the alignment of all table legs (B&C), and adjust if necessary. Once the alignment is correct and all bolts & nuts are in place, tighten all nuts (I) using wrench (L). Cover all nuts (I) with nut covers (J). With the help of another person, carefully turn the table to the upright position. The table is ready for your enjoyment.

