
Yale® Tri-Pack 50 Series

Non Handed Door Closer



Installation Instructions

80-9350-2502-010 (12-09)

An Incorrectly installed or improperly adjusted door closer can cause property damage or personal injury. These installation instructions should be followed to avoid the possibility of misapplication or misadjustment.

Non Hold Open Models

Sized (Sizes 2,3,4,5,6)

Weaker 52BC 53BC

Stronger

54BC 55BC 56BC Adjustable (Sizes 3 thru 6)

(Sizes 1 thru 4)





The Habitat for Humanity®

"DL" suffix (Delayed Action) is an optional feature. A separate sheet is supplied showing closer adjustments.

NOTE: For special applications a separate door and frame preparation template is packed with these instructions. Use this instruction sheet for installation sequence and closer adjustments only.

- Doors should be hung on ball bearing or anti-friction hinges.
- A separate door stop is recommended.
- Door and frame must be properly reinforced.
- Adjust closing time speed between 3 and 7 seconds from 90° to 0°.
- These door closers should NOT be installed on the exposed side (weather side) of exterior doors.







50 Series

Non Hold Open Door Closers — Regular Arm

80-9350-2502-010 (12-09)




80-9350-2502-010 (12-09)




Non Hold Open Door Closers — Parallel Arm

80-9350-2502-010 (12-09)



50 Series

Non Hold Open Door Closers — **Top Jamb Arm**



50 Series Adjustments Page


80-9350-2502-010 (12-09)

Yale ® is a registered trademark of Yale Security Inc., an ASSA ABLOY Group company. Copyright © 2001, 2009, Yale Security Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.




An ASSA ABLOY Group brand

3000 Highway 74 East • Monroe, NC 28112 Tel: (800)-438-1951 • Fax: (800)-338-0965 www.yalecommercial.com



Spring Power Adjust 51 (BF) only



(Use 1/8" Hex Wrench for this Adjustment)

Adjustment Chart				Number of Turns Required				
	ď	TYPE	*	MAXIMUM DOOR SIZE				
	DOOR	OF INST.		34" (0.85M)	36" (0.90M)	40" (1.00M)	44" (1.10M)	48" (1.20M)
51BF	INTERIOR	Regular Arm Top Jamb	° TURNS OF ADJUSTME REW	1	1	2	3	3
		Parallel Arm		2	2	3	4	5
	EXTERIOR	Regular Arm Top Jamb		5	6	8	NOT RECOMMENDED USE 51	
		Parallel Arm		8	9	12		
51	INTERIOR	Regular Arm Top Jamb	TURNS OF OWER INT SCREV	2	4	6	9	11
		Parallel Arm		3	5	7	10	13
	EXTERIOR INTERIOR	Regular Arm Top Jamb		3	5	7	10	13
		Parallel Arm		5	7	10	14	16

*18 FULL (360°) TURNS MAXIMUM AVAILABLE = 8 Turns As Shipped

To identify your model:



2=52BC

3 - 6 = 51

3 = 53 BC

1-4=51BF

4=54BC

5=55BC

6=56BC

