
## C3-3DC INSTALL GUIDE

## **DIMENSIONAL RENDERINGS**



- √ 2 anchor points are located on each side of the doors interior frame (top, bottom, left and right)
- ✓ Due to wide variance of possible building materials, anchors are not included
- When inserting your anchors be sure to use a framing square to ensure the door is not pulled out of square
- ✓ Additional framing and/or support underneath the rear (hanging portion) of the cabinet is recommended
- These specs are accurate but we always suggest having the product physically on site to ensure full understanding of how this product will coordinate with your build

