


Exploded View and Replacement Parts



Blaze Part Number: Reference Guide				
1.	BLZ-20KMDO-006	10.	BLZ-20KMDO-001	
2.	BLZ-20KMDO-009	11.	BLZ-20KMDO-011	
3.	BLZ-20KMDO-005	12.	BLZ-20KMDO-010	
4.	BLZ-KMDO-SSHAND	13.	BLZ-20KMDO-008	
5.	BLZ-20KMDO-004	14.	BLZ-20KMDO-013	
6.	BLZ-20KMDO-007			
7.	BLZ-20KMDO-012			
8.	BLZ-20KMDO-003			
9.	BLZ-20KMDO-002			

