



Son of Hibachi®

ASSEMBLY INSTRUCTIONS


Available Directly At WWW.SONOFHIBACHIONLINE.COM



Insert the legs into the pre-drilled holes on frame of the barbecue.
CAUTION: Insert the legs so they flare outward.



Attach handles into charcoal trays by slipping both ends onto the grooves, then sliding each into the pre-drilled holes one side at a time.
NOTE: The handles should fit snugly. If not, tighten by bending both handles inward for spring tension.



Slide ash drawer into side of base as indicated by arrow. Position grills into lowest slot in grill holders.
NOTE: Grills must be in lower slot for proper closure.



Close barbecue and slide draft slide handle on top of the unit. Be certain draft slide handle faces the same direction as the ash drawer.

WARNING: Never use Son of Hibachi indoors or in any enclosed area. Always use Son of Hibachi on a non-combustible surface.

Limited Warranty: Son of Hibachi is warranted against defects for a period of 1 year from the date of purchase. The warranty does not cover any damage resulting from customer: negligence, handling, misuse, or improper assembly.

The cast iron grills may have some rust due to overseas shipping. Rust is neither a design nor mechanical defect and the warranty does not cover this condition. The grilling surface should be cleaned after unpacking.

Please e-mail you questions, comments and concerns to: sales@sonofhibachionline.com