



## ALTURI Cart Assembly Instructions Model # CART-ALT30 / CART-ALT36 / CART-ALT42

**STEP 1:** Remove packaging support beam (#1). This is used only for packaging and stabilization.

**STEP 2:** Remove protective film from surface of cart (recommended to wipe down with stainless steel cleaner once removed).

**STEP 3:** Using the hardware provided attach the rear shelf brackets (#4).

**STEP 4:** (2 people recommended for this step) With rear bracket in place put rear peg of the cart shelf (#2) through rear shelf bracket. Put front shelf bracket (#4) through front shelf peg and secure using provided hardware.

**STEP 5:** Using regulator access panel (#3) drop bottom in first and then secure top of panel using hardware provided.

