



IN GROUND PEDESTAL INSTALLATION INSTRUCTIONS

12028 E. PHILADELPHIA ST. WHITTIER CALIFORNIA 90601 U.S.A. www.rasmussen.biz

ATTENTION! READ INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY

WARRANTY

Rasmussen will repair or replace at our election any part that has failed due to defects in material or workmanship for a period of one year from date of purchase.


WARNING

This In Ground Pedestal **MUST** be securely installed and assembled in accordance with these instructions in all instances.

PEDESTAL BASE PARTS LIST

(see drawing on next page)

Item #	DESCRIPTION	QTY
A	SIDE PANELS - 1RH & 1 LH	2
B	REAR PANEL	1
C	TOP SUPPORT PLATE	1
D	REAR ACCESS PANEL	1
E	PEDESTAL SUPPORT	1
7004	PAN HEAD 1/4" X 20 1/2"	10
7012	HEX BOLTS 1/4" X 20 X 3/4"	28
7014	FLAT WASHERS	24
7011	SPRING WASHERS	28
3400	1/2" HOSE 48" LONG	1
7007	1/4" X 20 HEX NUTS	3



The installation **MUST** comply with all local codes and the gas line/connections should be carried out by an experienced Gas Installer. Read these instructions fully and identify the parts before proceeding further.

Installation Instructions

- 1) To support the post for an "In Ground" installation, dig a hole approximately 14" square and 18" deep. Insert the post then carefully pour in cement, ensuring that the post is vertical and level in all directions. Once the cement sets up (turns to concrete) proceed to step 2.
- 2) Place the Top Support Plate (Figure 1C) onto the Pedestal Support (Figure 1E) (see note below) and secure with eight $\frac{1}{4}$ " x 20 bolts, eight flat washers and eight split-washers. Tighten securely.
- 3) Place the Right and Left Side Panels (Figure 1A) into position, locating the bottom flange on top of the Top Support Plate (Figure 1C).
- 4) Bolt each Side Panel onto the Top Support Plate using two $\frac{1}{4}$ " x 20 x 1" hex head bolts from below.
- 5) Carefully position the BBQ over the two Side Panels and bolt down to the Drip Tray runners and the Side Panel bottom flange.
- 6) Install the supplied gas supply components. After making the incoming gas connection and testing the appliance for gas leaks in accordance with the instructions shown in the care and use manual. Fit the removable Rear Panel (Figure 1B) and the Rear Access Panel (Figure 1D) using the $\frac{1}{4}$ " x 20 x $\frac{1}{2}$ " pan head bolts, and flat washers provided.

FIGURE 1

