


MERANTI WOOD ROCKING CHAIR







FRN-287







Read this manual carefully before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.



Ensure all parts are accounted for before disposing of packaging.

No.	PARTS	QTY.
A	 Right Arm	1
B	 Left Arm	1
C	 Backrest	1
D	 Seat	1
E	 Support Bar	1
F	 Footrest	1

No.	HARDWARE	QTY.
1	 JCBC M6x40 Bolt	4
2	 JCBC M6x60 Bolt	6
3	 JCBC M6x80 Bolt	2
4	 Barrel Nut	8
5	 Hex Key	1
6	 Barrel Nut Driver	1



WARNING

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children away during assembly.


ASSEMBLY

Read carefully and understand assembly before beginning.

Do not fully tighten hardware until all components have been loosely assembled.

STEP 1

A: 1
B: 1
E: 1
F: 1
2: 2
3: 2
4: 4




- Insert two Barrel Nuts (4) into Support Bar (E). Use the Barrel Nut Driver to align the barrel nut with the holes on the outside of the support bar.
- Insert two Barrel Nuts (4) into Footrest (F). Use the Barrel Nut Driver to align the barrel nut with the holes on the outside of the footrest.
- Loosely secure Support Bar (E) to Right Arm (A) by hand-tightening one JCBC M6x60 Bolt (2), ensuring the bolt threads into the barrel nut.
- Ensuring the rounded edge faces forward, secure Footrest (F) to Right Arm Panel (A) by hand-tightening one JCBC M6x80 Bolt (3), ensuring the bolt threads into the barrel nut.
- Repeat the previous two steps to loosely attach Left Arm (B).

Do not fully tighten bolts until after Step 3 is complete.

STEP 2

D: 1
2: 4
4: 4




- Insert four Barrel Nuts (4) into Seat (D), as shown. Use the Barrel Nut Driver to align the barrel nut with the holes on the outsides of the seat.
- Loosely secure Seat (D) to the arm panels by hand-tightening four JCBC M6x60 Bolts (2), ensuring the bolts thread into the barrel nuts.

Do not fully tighten bolts until after Step 3 is complete.

STEP 3

C: 1
1: 4



- Align Backrest (C) between the arm panels, as shown.
- Loosely secure Backrest (C) to the arm panels by hand-tightening four JCBC M6x40 Bolts (1).
- Tighten all bolts from all steps using Hex Key (5).

Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface. Do not stand on the chair.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

CLEANING: Identify the direction of the woodgrain. Following the direction of the woodgrain, wipe surfaces with a soft, dry cloth. Do not use harsh chemicals or abrasive materials or a pressure washer to clean.

COVER: When not in use, cover furniture with a breathable cover to help protect it from the effects of sunlight, inclement weather, dust build-up, and collecting debris.

WINTER CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a cool, dry indoor location. Covering while in storage is recommended to help prevent dust build-up.

MAINTENANCE: If left untreated, the wood may weather. A suitable wood stain or oil may need to be applied yearly.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE USE OF CHEMICAL TREATMENTS OR PROTECTIVE COATINGS.

SAFETY STATEMENTS & WARNINGS

- Do not exceed the weight capacity of the furniture.
- Do not stand on the chair.
- Inspect hardware often and tighten loose hardware before use.
- Do not put hot items on or near furniture.
- Do not allow children to use this product without adult supervision.
- Do not use harsh chemicals or abrasive materials to clean the furniture.
- Do not use a pressure washer to clean the furniture.

Any modification to the product or failure to follow recommended care will void the product warranty.

WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.