


ASSEMBLY INSTRUCTIONS FOR OL1907 & OL1908:

02/01




IMPORTANT:

TURN OFF POWER AT MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

1. Carefully unpack and identify all parts before starting assembly. Bulbs are not included.
2. Thread fixture wire at bottom of center body thru lower pipe. Then screw lower pipe into center body.
3. Screw upper pipe into top of center body.
4. In following order thread fixture wire thru metal washer, rubber washer, main frame, bottom frame, post cup ground wire, teeth washer, and finally hex nut. Lock all these parts by tightening hex nut at bottom. Note: Main frame will still remain loose.
5. Install candle cover and bulbs onto sockets. Bulbs are not included. See relamping label near socket area for type and maximum allowed wattage.
6. Slip cover and top font thru upper pipe and lock into place with finial at top.
7. Electrical installation onto post: If you are replacing existing fixture, disconnect and remove the old fixture.
 - A) Slip post cup over post. Mark position of holes in post cup on post.
 - B) Remove post cup and expose the supply wiring from above post. Drill 1/8" diameter pilot holes in post at places where marked.
 - C) Make wire connections. (wire connectors not provided). Refer to chart below for correct connections. Wire supply wires to fixture wires accordingly.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black Fixture Wire or	White Fixture Wire or
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wire (SPT 1 & SPT2) is used. One wire is square shaped or ridged and the other wire will be round in shape or smooth. (See Illustration)



- D) Connect ground wire from supply source to fixture ground wire with connector. Never connect ground wire to black or white power supply wires. Carefully place wires inside post.
- E) Slip post cup onto post. Align holes in post cup with holes in post. Fasten with enclosed sheet metal screws.

© FEISS INDUSTRIES

MURRAY FEISS