


SIENA RECLINING ARMCHAIR

ITEM - SRCH



OXFORD GARDEN

About Shorea Wood

Shorea is a tropical hardwood that is comparable to teak. Because of its high oil content it is resistant to rotting, bug infestation, and the effects of wind, rain, sun, and snow. If left untreated shorea weathers naturally to a beautiful silver gray color. Some surface roughness may develop, especially at the end grain, but over a period of about one year, the natural weathering process will stabilize. Moderate checking in the grain is normal with exposure to the elements. Small surface cracks that may appear in no way affect the structural integrity of the furniture. As weather conditions and temperatures fluctuate these small cracks may expand and contract.

Wood Care Instruction

To prevent the staining of concrete or tile the furniture should be rinsed well after assembly to remove dust that might remain from the manufacturing process. Although shorea weathers well we recommend a routine application of teak oil or Cabot's Australian Timber Oil in extremely dry climates. A routine oiling is also recommended for furniture to be used for dining purposes to discourage staining from food and drink spills.

For seasonal cleaning rinse the furniture well and then scrub (using a sponge or soft bristle brush) with a mild solution of water, laundry detergent and a little bleach. Rinse with fresh water.


To restore the original wood color, Oxford Garden suggests applying Cabot's Australian Timber Oil or any high quality teak oil after cleaning. Test in an inconspicuous spot first, to approve the color. Application of oil is at the customer's discretion and is not covered by the warranty. Paint or any products with polyurethane are not recommended, as application of these products will void the warranty as well.

For additional information regarding our warranty, please visit www.oxfordgarden.com


Assembly Instructions page 1

Components


- ① Seat Back
QUANTITY: 1




- ② Seat
QUANTITY: 1



- ③ Right Leg Assembly
QUANTITY: 1



- ④ Left Leg Assembly
QUANTITY: 1



- ⑤ Front Seat Rail
QUANTITY: 1



- ⑥ Rear Seat Rail
QUANTITY: 1



Siena Reclining Armchair

Hardware

- A 10mm x 595mm Steel Rod
QUANTITY: 1
- B 10mm x 1mm Nylon Washer
QUANTITY: 2
- C 20mm x 20mm Polyethylene Blocks
QUANTITY: 2
- D Wooden Dowels
QUANTITY: 8
- E 10mm x 2mm Nylon Washer
QUANTITY: 2



Finishing Items (included)


Medium Grit Sandpaper

NOTE: A hammer (not provided) will be needed for the assembly of this chair.

NOTE: If the furniture is going to be placed on a concrete or tile patio, it should first be rinsed well to remove the sawdust that may cause some staining.


Step 1

First prepare the seat assembly. Insert the steel rod **A** through the pre-drilled holes of the seat back **①** and seat **②**. Place the nylon washer **B** on the rod followed by the polyethylene blocks **C** as shown.




Step 2

On a clean flat surface, lay right leg assembly **③** on its side mortise holes facing up. Place front seat rail **⑤**, and rear seat rail **⑥** into mortise of right leg assembly. A steel pin indicates the rear of the chair. Next, slide the 2mm washer **E** onto the steel pin at the rear of the chair.




Step 3

Line up the completed seat assembly so the polyethylene block fits into the long mortise in the rail on the right leg assembly and the steel pin of the leg assembly fits into the mortise located on the seat back.



Step 4

Place left leg assembly **④** onto those parts already assembled. Again, slide the 2mm washer onto the steel pin, align the polyethylene block and the steel pin to fit into the mortise of the rail on the left leg assembly and the seat back.



Step 5

With a hammer, drive 8 total dowels **D** into the predrilled holes found on the front and rear of the leg assemblies. Insert the tapered end of the dowels first. NOTE: The dowels should be easily driven in flush. If there is strong resistance, do not force the dowel. Sand to smooth off areas around the dowel pins. Your chair is now ready to enjoy!

